

Installation Instructions for mounting HLT Liners/Ventilators in wood range hoods

T-Shape Liners are to be used only with Range Hood Fronts.

- 1) Mount wall cabinets as outlined by manufacturer allowing 1/8" more space than specified range hood width (i.e.; for 30" liner use 30-1/8" spacing).
- 2) Exposed wood edges should be no less than 30" above cooking surface.
- 3) Drill 2-3 pilot holes horizontally through wall cabinet face frame on each side where range hood front is to be mounted.
- 4) Mount ventilation Power Pack securely to T-Shape Steel Liner as outlined in ventilator instruction packet.
- 5) Choose appropriate height and locate Liner/Ventilator assembly between two adjacent wall cabinets so that the bottom edge of the liner is a minimum of 30" above cooking surface and touching rear wall.
- 6) Position liner as shown so narrow portion is in front (a).
- 7) Remove protective peel coat from liner (if applicable).
- 8) Secure Liner/Ventilator assembly to adjacent wall cabinets with wood screws (#6 x 1/2" not included).
- 9) Fasten Liner assembly to rear wall, screwing into studs where available. If studs are not available, install using drywall anchors.
- 10) Install duct work or ductless kit to ventilator power pack according to manufacturer's guidelines.
- 11) Fit Range Hood Front into opening between adjacent wall cabinets so it is flush with wall cabinet face frame and covering Liner/Ventilator assembly.
- 12) Secure Range Hood front to adjacent wall cabinets on both sides using framing screws (#8 x 2-1/2").

